

# PARTITION INSTALLERS SPECIFICATION

Ria Thompson, DenDesignery +647 500 6518 ria@dendesignery.com www.dendesignery.com

## 1 MAIN DETAILS

PROJECT DETAILS						
NAME:		SITE ADDRESS:			CLIENT I	NAME:
3-Bedroom Detached House Show	Home	<site address=""></site>			<client na<="" td=""><td>ame&gt;</td></client>	ame>
CONTRACTOR DETAILS						
NAME: ADDR			PHONE			E-MAIL:
<contractor's name=""></contractor's>	<contra< td=""><td>actor's address &gt;</td><td>office: &lt;###&gt;</td><td>mobile: &lt;###</td><td><i>#&gt;</i></td><td><contractor's e-mail=""></contractor's></td></contra<>	actor's address >	office: <###>	mobile: <###	<i>#&gt;</i>	<contractor's e-mail=""></contractor's>

GENI	ERAL INSTRUCTIONS and PREPATORY NOTES
1/	Please review this specification, the reference drawings and schedules and contact me as soon as possible with any issues or questions.
2/	This specification has separate sections for each of the partitions to be installed: Section 2 for the partition designated for the Downstairs Bathroom (Ground Floor), and Section 3 for the partition designated for the Shower Room (First Floor).
3/	Important scheduling note for coordination with the flooring contractors: Both partitions must be installed after the vinyl floors in both bathrooms have been installed.
4/	Please carry out all work with appropriate care taken so that no damage is inflicted on the newly installed floors.
5/	No substitutions are to be made unless agreed upon ahead of time.
6/	The specific manufacturer's instructions are to be followed in each case.
7/	As much as possible, please leave the work areas in a tidy fashion at the end of each day. All rubbish is to be promptly removed from the site.



# PARTITION INSTALLERS SPECIFICATION

Ria Thompson, DenDesignery +647 500 6518 ria@dendesignery.com www.dendesignery.com

## **2 DOWNSTAIRS BATHROOM**

	PRODUCT DETAILS							
Ref ID within room	TYPE	BRAND / SUPPLIER	NAME	CODE / REF	COLOUR	DIMS INFO (mm)	REFERENCE DRAWING	INSTALLATION NOTES and WWW LINKS
4	Partition	3form	Varia Ecoresin / Organics / Criss Cross	Installation Solution Code for Top Support Suspended Partition: 200.25.01	White, brown	Gauge: 12.7 (1/2") Custom sized: 900W x 2298.4H  101.6 (4") is the allowance for fitting the top and bottom hardware channels that will hold the partition in place [Panel height (2298.4) = Opening height(2400) - 4"].	(D5) Painter/ Decorator/ Installer - Ground Floor  (See label on drawing)	Product info: http://www.3-form.com/materials/varia_ecoresin/organics/criss_cross/#4  To be installed using the Top Support system with surface mounted (to floor and ceiling) hardware channels. For more info: http://www.3-form.com/ready_to_go/partitions/200.25/  Detailed installation instructions: http://www.3-form.com/downloads/ 3form_harspec_topsupport_Man-026_Rev006.pdf  Please see this manual for instruction on how to trim the panel if any height adjustment is necessary: http://www.3-form.com/downloads/ 3form_Varia_Fabrication_Manual_REV007.pdf



# PARTITION INSTALLERS SPECIFICATION

Ria Thompson, DenDesignery +647 500 6518 ria@dendesignery.com www.dendesignery.com

## 3 SHOWER ROOM

Ref ID within room	TYPE	BRAND / SUPPLIER	NAME	CODE / REF	COLOUR	DIMS INFO (mm)	REFERENCE DRAWING	INSTALLATION NOTES and WWW LINKS
4	Partition	3form	Varia Ecoresin / Wood / Zebrano Chevron	Installation Solution Code for Top Support Suspended Partition: 200.25.01	Brown	Gauge: 12.7 (1/2") Custom sized: 900W x 2298.4H  101.6 (4") is the allowance for fitting the top and bottom hardware channels that will hold the partition in place [Panel height (2298.4) = Opening height(2400) - 4"].	(D6) Painter/ Decorator/ Installer - First Floor  (See label on drawing)	Product info: http://www.3-form.com/materials/varia_ecoresin/wood/zebrano_chevron/  To be installed using the Top Support system with surface mounted (to floor and ceiling) hardware channels. For more info: http://www.3-form.com/ready_to_go/partitions/200.25/  Detailed installation instructions: http://www.3-form.com/downloads/ 3form_harspec_topsupport_Man-026_Rev006.pdf  Please see this manual for instruction on how to trim the panel if any height adjustment is necessary: http://www.3-form.com/downloads/ 3form_Varia_Fabrication_Manual_REV007.pdf